



REMIglas care product

Care instructions for REMIglas products

Correct care is a necessary element in maintaining the smooth-running functioning of glass covers.

No aggressive cleaning agents or scrubbing may be used for the cleaning process.

Care of running surfaces

The running profiles are pre-treated ex works so that the sliding covers run as smoothly as possible. Smooth running is maintained for a long period of time on a clean running surface.

It is recommended that the running surfaces are treated every 3 - 6 months with the REMIS care product, depending on the degree of contamination. Contaminated running surfaces should be cleaned with a damp cotton or microfibre cloth and then treated with REMIS care product.

The REMIS care product should be applied sparingly, so that a very thin film forms on the surface. Excess amounts should be soaked up with a cloth.



11,50 €

Cleaning the sliding covers

The glass surfaces and profiles can be cleaned from both sides with a standard glass cleaner.

Cleaning plastic and powder-coated surfaces

Slightly contaminated surfaces should be cleaned with a damp cotton or microfibre cloth. If the plastic profile is highly contaminated, a PVC plastic cleaner should be used. Running profiles should then be treated again with REMIS care product.



REMIS GmbH
Mathias-Brüggen-Str. 67-69
D-50829 Köln

Tel. +49 (0) 221 / 7 88 80 - 0
Fax +49 (0) 221 / 7 88 80 - 249
remis@remis.de · www.remiglas.de